



Instructions for use



1. rough up the surface





2. apply vulcanizer
solution



3. perforate the label





3. pull down the paper
from the backside



4. apply the label



6. after removing from
the autoclave and coating
tire take out the covering foil

